

RELAY CATALOGUE 2024



OUR COMMITMENT TO QUALITY, INTEGRITY, AND CUSTOMER SATISFACTION IS EVIDENT IN EVERY ASPECT OF OUR OPERATIONS.

CALL US +971-502530752 +971-544353367

> MORE INFO www.autorod.ae



RELAY





MORE INFO

Product Description

Circuit Breakers



Overload protection: Circuit breakers are designed to automatically interrupt an electrical circuit when they detect an overload, protecting against electrical hazards and damage to equipment.

Short-circuit protection: Circuit breakers also protect against short-circuits by automatically interrupting the flow of electricity when they detect a fault in the circuit.

Resettable: Most circuit breakers can be easily reset after they trip, allowing for quick and convenient restoration of power.

Automotive fuse



Fuses come in different shapes, sizes, and amperage ratings to match the specific needs of the electrical system in a car.

They are typically made of a metal wire or filament that melts when too much current flows through it, interrupting the flow of electricity and preventing damage to the vehicle's electrical components.

Fuse Holder



Fuse holders come in different types, including blade fuse holders, mini fuse holders, and maxi fuse holders, to match the different sizes and types of fuses used in a vehicle.

They are typically made of a durable, heat-resistant material such as plastic or metal and are designed to securely hold the fuse in place, while providing easy access for maintenance and replacement.

Battery Terminals



Battery terminals come in two main types: positive and negative. The positive terminal is usually marked with a "+" symbol, while the negative terminal is marked with a "-" symbol. Both terminals are usually made of brass or other conductive materials and are designed to fit snugly onto the battery posts.

Battery terminals may also include a terminal cover, which is a protective cover that fits over the terminals to prevent accidental contact and provide additional protection from environmental factors such as moisture, dirt, and corrosion.

Battery Connector 🥣 🦛 🐔

Battery connectors come in different types, including clamp connectors, eyelet connectors, and plug-and-socket connectors.

Clamp connectors, also known as battery clamps, are the most common type of battery connector and are used to secure the battery cable to the battery post. They consist of a metal clamp that fits over the battery post and a screw or bolt that tightens down to secure the cable in place.

Relay



Relays are used in cars because they allow the control of highpower circuits with a low-power signal, typically from a switch or control module.

This helps to reduce the size and weight of the wiring and switches in a vehicle, and also helps to protect the electrical system by isolating the high-power circuit from the control circuit.



Car battery accessories are a group of components and devices that are used to support the operation and maintenance of a car's battery.

These accessories are designed to enhance the performance, efficiency, and longevity of the battery, as well as to provide safety and protection for both the battery and the vehicle.

Application Of Relay

Relays can be used in various applications, including:

Electric power control: relays can be used to control the power supply to electric motors, lighting systems, and other high-power devices.

Automotive industry: relays are used in cars and other vehicles to control the ignition system, fuel pump, headlights, and other electrical systems.

Industrial automation: relays are commonly used in factories and other industrial settings to control machinery and other equipment.

Home automation: relays can be used in home automation systems to control lighting, heating, and other household appliances.

Telecommunications: relays are used in telephone exchanges to route calls and other signals to their destinations.

Security systems: relays can be used in security systems to trigger alarms, control access to buildings, and perform other security-related functions.



Features of Relay

Switching capability:

Relays are designed to switch or control the flow of electrical current or signal to a specific device or system.

Contact configuration:

Relays have various contact configurations, including normally open (NO), normally closed (NC), and changeover (CO) contacts.

Contact rating:

Relays have different contact ratings that specify the maximum voltage and current that they can handle safely.

Coil voltage rating:

Relays require a specific voltage to activate the coil and operate the switch contacts.

Response time:

Relays have a response time, which is the time it takes for the switch contacts to close or open after the coil is energized or de-energized.

Physical design:

Relays come in different sizes and shapes and can be designed for various mounting methods, including PCB mounting and panel mounting.

Relay



High Current Relay P004-201-0001


*Rated Voltage: 12Vdc

*Rated Current: 150A


*Ambient Temperture: -40 ° C ~ +125° C

*Operation Voltage : \leq 8Vdc(23° C)

*Release Voltage : \geq 1.2Vdc(23° C) Voltage : \leq 8Vdc(23° C)











SCB RELAY P004-201-0002


*Normal voltage : 12VDC


*Coil resistance : 103 \pm 10.3 Ω at 20° C

*Operate voltag: 7.8VDC at 20° C

*Release voltage : 1.2VDC at 20° C

*Insulation resistance : 50MΩ Min. (500VDC)







MINI RELAY P004-201-0003


*Size: 27.5x 23.2x 49.3.


*Multiple choices for cover type.


*Contact rated load up to 30A / 12VDC.

*Application for air condition control, halogen head lamp control horn control, fog lamp control, etc.

*RoHS 2011/65/EU compliant.








Relay



Automotive 5-Pin Relay P004-201-0004 *Coil voltage : 12VDC

*Coil Resistance : 90Ω *Contact current DC, A : 40A *Contact configuration : SPDT *Mounting type : Bracket Cover





4-Pin Multipurpose Relay

P004-201-0005


*Rated Voltage: 12VDC

*Resistance: 77 Ω

*Contact current: 30A


*Operating Voltage : \leq 8VDC

*Release Voltage : ≥ 1.2 VDC



85

87





Solenoid Starter Switch P004-201-0006

*Rated Voltage: 12Vdc
*Rated Current: 100A
*Operating Voltage: ≤ 8.4Vdc
*Release Voltage: ≥ 1.2Vdc
*Operating Temp: -40° C ~ +85° C

